

## PRODUCT ASSEMBLY >



Loosen the fixed screw to adjust the left and right distance of the bracket



The fixed nut can be loosened to adjust the laser angle 360 degrees



Aluminum ring  $\Phi 26.3\text{mm}$   
This bracket is suitable for  $\Phi 26\text{mm}$  laser